

# SĀFTRON

## EXERCISE / SAFETY GRAB BARS / TOWEL BARS

### Installation instructions:

Can attach to concrete, marcite pool walls, or installed outside pools to any suitable surface and used as grab bars, door handles or towel bars.

### Notes:

- Non-conductive material does not require grounding.
- Kits include all necessary hardware for 15 minute installation.
- Grab Bars will only be as rigid and secure as the supporting foundation. Before installing make sure surface is suitable.
- Avoid scratches. Keep Ex-Bars in box until ready to install. Don't place Ex-Bars on bare ground.

### Installation Instructions



**1.** Mark post locations.



**2.** Use mounting to caps to mark centers.



**3.** Drill hole in masonry with provided bit to depth of 2, 1/2".



**4.** Clean hole and insert anchors.



**5.** Firmly attach mounting caps with provided lag bolts and washers.



**6.** Apply adhesive to inside surface of safety/exercise bar.



**7.** Tap safety/exercise bar onto mounting caps.



**8.** Wait 30 minutes then .....  
**ENJOY!**

**CAUTION:** Safety rails should be installed by licensed contractor. If self-installing, make sure pool is empty or use a battery operated drill. Never use A/C powered tools near water.

Saftron Manufacturing, LLC · Phone (305) 233-5511 · Fax (941) 751-2802 · [www.saftron.com](http://www.saftron.com) · [info@saftron.com](mailto:info@saftron.com)